


FLY REEL **730**

AVERY[™]
PV119G



Key No.	Parts No.	Parts Name
1	130-4701	Cover
2	144-1801	Spool stopper spring
3	541-3401	Spool stopper
4	B05-5001	Cover screw
5	375-3801	Cover washer
6	734-6501	Spool
7	701-6401	Body
8	030-6901	Click claw
9	310-2201	Line guard
10	350-8912	Line guard screw